


BIOS BIOS Disabled F4


Before updating the BIOS, enter the BIOS to turn off the security boot

then press F4 to save and exit




U FAT32 BIOS U

Format the USB flash drive to FAT32 Extract BIOS files to USB



BIOS Update F7 USB

Insert the USB into the computer, press F7 and select usb boot. Wait for BIOS update



BIOS Update

After the update is complete, the BIOS will restart

```
blk5 :BlockDevice - Alias (null)
      PciRoot(0x0)/Pci(0x2,0x2)/Pci(0x0,0x0)/NVMe(0x1,56-34-30-AA-74-A7-79-64
)
blk6 :Removable BlockDevice - Alias (null)
      PciRoot(0x0)/Pci(0x8,0x1)/Pci(0x0,0x3)/USB(0x1,0x0)/USB(0x1,0x0)
```

Press ESC in 1 seconds to skip **startup.nsh**, any other key to continue.

```
+-----+
|               AMI Firmware Update Utility v5.15.02.0078               |
|      Copyright (c) 1985-2022, American Megatrends International LLC.      |
|      All rights reserved. Subject to AMI licensing agreement.            |
+-----+
Reading flash ..... Done
- FFS Checksums ..... Pass
- Check RomLayout ..... Pass
Erasing Main Block ..... Done
Updating Main Block ..... Done
Verifying Main Block ..... Done
Erasing Boot Block ..... Done
Updating Boot Block ..... Done
Verifying Boot Block ..... Done
Erasing NVRAM Block ..... Done
Updating NVRAM Block ..... Done
Verifying NVRAM Block ..... Done
_Erasing NCB Block ..... 0x00288000 (24%)
```